

KEB 00.F4.010-1009

Operator Interface



Limited Availability
Used and in Excellent Condition

[Open Web Page](#)

<https://www.artisantg.com/91589-6>

All trademarks, brandnames, and brands appearing herein are the property of their respective owners.

- Critical and expedited services
- In stock / Ready-to-ship
- We buy your excess, underutilized, and idle equipment
- Full-service, independent repair center

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.




Your **definitive** source
for quality pre-owned
equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

COMBIVERT

F4-S



F4-C



BETRIEBSANLEITUNG
INSTRUCTION MANUAL
MANUEL D'INSTRUCTION
MANUALE DIISTRUZIONE
MANUAL DE INSTRUCCIONES
РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ

Steuerteil
Control circuit
Carte de commande
Circuito di controllo
Circuito de control
Карта управления



Erst Betriebsanleitung Teil
Read Instruction manual part
Lisez d'abord le manuel d'instructions partie
Prima leggere le manuale di istruzione parte
Leer manual de instrucciones parte
Сначала прочти инструкцию часть

1

lesen!
before!
!
! antes!

KEB

**Steuerteil****Seite 4 23****D****Control circuit****Page 24 43****GB****Carte de commande****Page 44 63****F****Circuito di controllo****Page 64 83****I****Circuito de control****Page 84 103****E****Карта управления****Страница 104 ... 123****RU****Passwords****Page 129**

This Instruction Manual describes the control boards F4-C(compact) and F4-S(mall). It is only valid together with the Instruction Manuals COMBIVERT F4 Part 1 and Part 2. Both Instruction Manuals must be made available to the user. Prior to performing any work on the unit the user must familiarize himself with the unit. This includes especially the knowledge and observance of the safety and warning directions of Part 1. The pictographs used in this Instruction Manual have following meaning:

Danger
Warning
Caution



Used when life or health of the user are exposed to danger or when severe damage to the material can occur.

Attention,
observe at



Special instructions for a safe and trouble-free operation.
at all costs

Tip
Help
Information



Used to mark additional important informations.

Attention

Only qualified
Electro-personnel

The KEB COMBIVERT is operated with voltages that can cause a severe electric shock dangerous to life. Therefore the installation of the unit as well as of the available accessories is only permissible by qualified electro-personnel. A safe and trouble-free operation is only possible when the valid regulations according to DIN VDE 0100, IEC1000, EN 60204-1, EN 55014, EN 50082-2 as well as the relevant regulations for your area are observed.

Danger

Note capacitor
discharge time

After clearing the frequency inverter the intermediate circuit capacitors are still charged with high voltage for a short period of time. The unit can be worked on again after it has been switched off for 5 minutes.


Table of Contents

1.	Installation and Connection..	26
1.1.	Control circuit Version C..	26
1.1.1	<i>Assignment of Terminal Strip X1</i>	26
1.1.2	<i>Connection of the Control</i>	27
1.1.3	<i>Digital Inputs</i>	27
1.1.4	<i>Analog Inputs</i>	27
1.1.5	<i>Outputs</i>	27
1.2	Control circuit Version S	28
1.2.1	<i>Assignment of Terminal Strip X1</i>	28
1.2.2	<i>Connection of the control</i>	28
1.2.3	<i>Digital inputs</i>	28
1.2.4	<i>Analog inputs</i>	28
1.2.5	<i>Outputs</i>	29
2.	Operation of the unit	29
2.1	Digital operator	29
2.1.1	<i>Interface operator</i>	29
2.1.2	<i>Keyboard</i>	30
2.2	Parameter Summary	31
2.3	Password Input	31
2.4	Operating Display	32
2.5	Basic Adjustment of the Drive	33
2.6	Special Adjustments	35
2.7	The Drive Mode	41
2.7.1	<i>Start / Stop Drive</i>	41
2.7.2	<i>Change Direction of Rotation</i>	41
2.7.3	<i>Preset Set Value</i>	41
2.7.4	<i>Leave Drive Mode</i>	41
3.	Error Diagnosis	42
4.	Passwords	129

1. Installation and Connection

1.1. Control circuit Version C

1.1.1 Assignment of Terminal Strip X1



PIN	Function	Name	Description
X1.1	NO contact	RLA	Relay output
X1.2	Opening contact	RLB	Function see parameter CP.22
X1.3	Switching contact	RLC	(factory setting: fault indication)
X1.4	Fixed frequency 1	I1	X1.4 + X1.5 = fixed frequency 3
X1.5	Fixed frequency 2	I2	no input = analog set value
X1.6	DC-braking	I3	activates the dc-braking
X1.7	Energy saving funct.	I4	Output voltage is reduced to 70%
X1.8	REF+	REF+	Difference voltage; Voltage difference is added to/
X1.9	REF-	REF-	subtracted from inputREF (X1.17)
X1.10	Forward	F	Preset rotation; forward has priority
X1.11	Reverse	R	
X1.12	Frequency depend.	OUT1	Transistor output switches at switch $f_{real} = f_{set}$
X1.13	Digital Mass	0V	Potential for digital in-/outputs
X1.14	15V	+15V	voltage supply for digital in-/outputs (max.100mA)
X1.15	Analog output	AOUT	Analog output of the real frequency 0...10VDC = 0...100Hz
X1.16	+10V	CRF	Supply voltage for set value potentiometer (max. 4 mA)
X1.17	Set value input	REF	Factory setting 0...10V (0...20 and 4...20mA adjustable with CP.24)
X1.18	Common	COM	Mass for analog in- and outputs
X1.19	Control release	ST	Power modules are triggered; if opening in case of error Reset; if opening during operation, the motor costs.
X1.20	Reset	RST	Hardware reset; only possible when an error occurs
X1.21	NO contact	FLA	Relay output; switches,when level
X1.22	Opening contact	FLB	from parameter CP.23 is reached
X1.23	Switching contact	FLC	(frequency dependent switch)


1.1.2 Connection of the Control

In order to prevent a malfunction caused by interference voltage supply on the control inputs, the following directions should be observed:



- Use shielded/drilled cables
- Lay shield **on one side** of the inverter onto earth potential
- Lay control and power cable **separately** (about 10...20 cm apart)
- Lay crossings in a right angle (in case it cannot be prevented)


1.1.3 Digital Inputs



1.1.4 Analog Inputs



Connect unused analog inputs to common, to prevent set value fluctuations!




1.1.5 Outputs



In order to prevent undefined conditions during external power supply, the external power supply should be switched on first and then the inverter.

When using inductive consumers at the relay output a protective wiring (i.e. free wheeling diode) is necessary to protect the relay!



Installation and Connection

1.2 Control circuit

Version S

1.2.1 Assignment of Terminal Strip X1



PIN	Function	Name	Description
X1.1	NO contact	RLA	Relay output
X1.2	Opening contact	RLB	Function see parameter CP.22
X1.3	Switching contact	RLC	(factory setting: fault indication)
X1.4	Fixed frequency 1	I1	X1.4 + X1.5 = fixed frequency 3
X1.5	Fixed frequency 2	I2	no input = analog set value
X1.6	Digital Mass	0V	Potential for digital in-/outputs
X1.7	+10V	CRF	Supply voltage for set value potentiometer (max. 4mA)
X1.8	Set value input	REF	0...10VDC for analog set value
X1.9	Common	COM	Mass for analog in- and outputs
X1.10	Analog output	AOUT	Analog output of real frequency 0...10VDC = 0...100Hz
X1.11	15V	+15V	voltage supply for digital in-/outputs (max. 100mA)
X1.12	Reverse	R	Preset rotation; forward has priority
X1.13	Forward	F	
X1.14	Control release	ST/RST	Power modules are triggered; if opening in case of error Reset; if opening during operation, the motor costs.


1.2.2 Connection of the control

In order to prevent a malfunction caused by interference voltage supply on the control inputs, the following directions should be observed:




- Use shielded/drilled cables
- Lay shield **on one side** of the inverter onto earth potential
- Lay control and power cable **separately** (about 10...20 cm apart)
- Lay crossings in a right angle (in case it cannot be prevented)

1.2.3 Digital inputs




1.2.4 Analog inputs

Internal analog set-point setting 0...10V




External analog set-point setting



1.2.5 Outputs



When using inductive consumers at the relay output a protective wiring (i.e. free wheeling diode) is necessary to protect the relay!



2. Operation of the unit

As an accessory to the local operation an operator is necessary. To prevent malfunctions, the inverter must be brought into **nOP** status before connecting/disconnecting the operator (open control release terminal X1.19 **C-Version**/X1.14 **S-Version**). When starting the inverter without an operator, it is started with the last stored values or factory setting. The operator is obtainable in different versions:

2.1 Digital operator

Part-No. 00.F4.010-2009

Interface control
Transmit "LED flickers"



Operating-/Error display
Normal "LED on"
Error "LED blinks"

Double function keyboard

2.1.1 Interface operator

Part-No. 00.F4.010-1009

In the Interface operator there is an additionally isolated RS232/RS485-Interface integrated.



PIN	RS485	Signal	Meaning
1	-	-	reserved
2	-	TxD	Transmitter signal/RS232
3	-	RxD	Receiver signal/RS232
4	A'	RxD-A	Receiver signal A/RS485
5	B'	RxD-B	Receiver signal B/RS485
6	-	VP	Voltage supply-Plus +5V ($I_{max} = 10 \text{ mA}$)
7	C/C'	DGND	Data reference potential
8	A	TxD-A	Transmitter signal A/RS485
9	B	TxD-B	Transmitter signal B/RS485

Informations about other versions of operators contact KEB!

Operation of the Unit


2.1.2 Keyboard

When switching on KEB COMBIVERT the value of parameter CP.1 appears. (See Drive mode to switch the keyboard function)

The **function key (FUNC)** changes between the parameter value and parameter number.



With **UP** and **DOWN** the value of the parameter number is increased/decreased with **changeable** parameters.



Principally during a change, parameter values are immediately accepted and stored non-volatile. With some parameters it is not useful, that the adjusted value immediately be accepted. When this type of parameter is changed, then a point appears behind the last digit.

By pressing **ENTER** the adjusted value is accepted and non-volatile stored.



If a malfunction occurs during operation, then the actual display is overwritten by the alarm message. The alarm message in the display is reset by **ENTER**.



With **ENTER** the error message is only reset in the display. In order to reset an error oneself, the cause must be removed and a reset on terminal X1.20 (C-Version) / X1.14 (S-Version) or a power-on reset must occur. In the Inverter status display (CP. 2) the error is still displayed.



2.2 Parameter Summary

Display	Parameter	Adjust. range	Resolution	Factory setting
CP. 0	Password input	0...9999	1	-
CP. 1	Actual frequency display	-	0,1 Hz	-
CP. 2	Inverter status display	-	-	-
CP. 3	Actual load	-	1 %	-
CP. 4	Peak load	-	1 %	-
CP. 5	Rated frequency	0...409.58 Hz	0.0125 Hz	50.0 Hz
CP. 6	Boost	0...25.5 %	0.1 %	2 %
CP. 7	Acceleration time	0.01...300 s	0.01 s	10 s
CP. 8	Deceleration time	0.01...300 s	0.01 s	10 s
CP. 9	Minimal frequency	0...409.58 Hz	0.0125 Hz	0 Hz
CP.10	Maximal frequency	0...409.58 Hz	0.0125 Hz	70 Hz
CP.11	Fixed frequency 1	0...±409.58 Hz	0.0125 Hz	5 Hz
CP.12	Fixed frequency 2	0...±409.58 Hz	0.0125 Hz	50 Hz
CP.13	Fixed frequency 3	0...±409.58 Hz	0.0125 Hz	70 Hz
CP.14	Max. ramp current	10...200 %	1 %	140 %
CP.15	Max. constant current	10...200 %	1 %	200 %
CP.16	Speed search	0...15	1	8
CP.17	Voltage stabilization	150...649 V, off	1 V	off
CP.18	Slip compensation	-2.50...2.50	0.01	0=off
CP.19	Autoboost	-2.50...2.50	0.01	0=off
CP.20	DC-braking	0...9	1	7
CP.21	Braking time	0...100 s	0.01 s	10 s
CP.22	Relay output	0...xx	1	2
CP.23	Frequency value	0...409.58 Hz	0.0125 Hz	4 Hz
CP.24	Reference signal (only C)	0...2	1	0


2.3 Password Input

CP. 0


Passwords on
Page 129

If works the frequency inverter is supplied without password protection, this means that all changeable parameters can be adjusted. After parameterizing the unit can be barred against unauthorized access. The adjusted mode is stored.

Barring the CP-Parameter



Releasing the CP-Parameter



Operation of the Unit

2.4 Operating Display

Actual frequency display



The 4 parameters below serve to control the frequency inverter during operation.

Display of the actual output frequency with a resolution of 0.0125 Hz. The rotation of the inverter is indicated by the sign.

18.3

Output frequency 18.3 Hz, rotation forward

Examples:

- 18.3

Output frequency 18.3 Hz, rotation reverse

Inverter status display



The status display shows the actual working conditions of the inverter. Possible displays and their meanings are:

nOP

" no Operation " control release (terminal X1.19) not bridged, modulation switched off, output voltage = 0 V, drive is not controlled.

L5

" Low Speed " no rotation preset (terminal X1.10 or X1.11), modulation switched off, output voltage = 0 V, drive is not controlled.

FAcc

" Forward Acceleration " drive accelerates with a forward direction of rotation.

FDec

" Forward Deceleration " drive decelerates with a forward direction of rotation.

rAcc

" Reverse Acceleration " drives accelerates with a reverse direction of rotation.

rDec

" Reverse Deceleration " drive decelerates with a reverse direction of rotation.

Fcon

" Forward Constant " drive runs with a constant speed and a forward direction of rotation.

rcon

" Reverse Constant " drive runs with constant speed and a reverse direction of rotation.

Other status messages are described at the parameters, which they cause.

Actual load



Display of the actual inverter rate of utilization in percent. 100% rate of utilization is equal to the inverter rated current. Only positive values are displayed, meaning there is no differentiation between motor and regenerative operation.

Peak load



This display makes it possible to recognize short-term fluctuations of the rate of utilization by storing the highest value that occurred. The display occurs in percent (100% = inverter rated current).



With the UP or DOWN key the peak value can be reset when the unit is on. As a result it is possible to measure the highest rate of utilization in certain operating phases. Switching off the unit deletes the peak value.

2.5 Basic Adjustment of the Drive


Rated frequency

CP. 5

The following parameters determine the fundamental operating data of the drive. They should be checked and/or adapted to the application.

With the adjusted frequency here the inverter reaches a maximal output voltage. The adjustment of the motor rated frequency is typical here. Note: Motors can overheat when the rated frequency is incorrectly adjusted!

Adjustment range: 0...409.58 Hz
 Resolution: 0.0125 Hz
 Factory setting: 50.0 Hz
 Customer adjustment: _____ Hz




GB

Boost

CP. 6

In the lower speed range a large part of the motor voltage decreases on the stator resistance. In order that the breakdown torque of the motor remains almost constant in the entire speed range, the voltage decrease can be compensated by the boost.

Adjustment range: 0...25.5 %
 Resolution: 0.1 %
 Factory setting: 2.0 %
 Customer adjustment: _____ %



Adjustment: - Determine the rate of utilization in no-load operation during rated frequency
 - Preset about 10 Hz and adjust the boost, so that about the same rate of utilization is reached as with the rated frequency.



When the motor, during continuous operation, drives with low speed and too high voltage it can lead to an overheating of the motor.


Acceleration time

CP. 7

The parameter determines the time needed, in order to accelerate from 0 to 100 Hz. The actual acceleration time is proportional to the frequency change.

$$\frac{\text{delta } f}{100 \text{ Hz}} \times \text{CP. 7} = \text{actual acceleration time}$$

Adjustment range: 0.01...300 s
 Resolution: 0.01 s
 Factory setting: 10 s
 Customer adjustment: _____ s



Example: CP. 7 = 10 s ; the drive should accelerate from 10 Hz to 60 Hz
 $\text{delta } f = 60 \text{ Hz} - 10 \text{ Hz} = 50 \text{ Hz}$

$$\text{actual acceleration time} = (50 \text{ Hz} / 100 \text{ Hz}) \times 10 \text{ s} = 5 \text{ s}$$

Operation of the Unit


Decceleration time

CP. 8

The parameter determines the time needed in order to decelerate from 100 to 0 Hz. The actual deceleration time is proportional to the frequency change.

$$\frac{\text{delta } f}{100 \text{ Hz}} \times \text{CP. 8} = \text{actual deceleration time}$$

Adjustment range: 0.01...300 s
Resolution: 0.01 s
Factory setting: 10 s
Customer adjustment: _____ s



Example: CP. 8 = 10 s ; the drive should decelerate from 60 Hz to 10 Hz
delta f = 60 Hz - 10 Hz = 50 Hz


$$\text{actual deceleration time} = (50 \text{ Hz} / 100 \text{ Hz}) \times 10 \text{ s} = 5 \text{ s}$$

Minimal frequency

CP. 9

Frequency on which the inverter runs without presetting an analog set value. Internal limiting of the fixed frequencies CP.11...CP.13.

Adjustment range: 0.0...409.58 Hz
Resolution: 0.0125 Hz
Factory setting: 0.0 Hz
Customer adjustment: _____ Hz



Maximal frequency

CP. 10

Frequency on which the inverter runs with maximum analog set value. Internal limiting of the fixed frequencies CP.11...CP.13.

Adjustment range: 0.0...409.58 Hz
Resolution: 0.0125 Hz
Factory setting: 70 Hz
Customer adjustment: _____ Hz

Fixed frequency 1...3

CP. 11 I₁

CP. 12 I₂

CP. 13 I_{1+I2}

Three fixed frequencies can be adjusted. The selection of the fixed frequencies occurs with the inputs I₁ and I₂ (terminal X1.4 and X1.5).

Adjustment range: 0.0...±409.58 Hz
Resolution: 0.0125 Hz
Factory setting: 5/50/70 Hz
Customer adjustment 1: _____ Hz
Customer adjustment 2: _____ Hz
Customer adjustment 3: _____ Hz

If presetting occurs outside of the fixed limits of CP.9 and CP.10, then the frequency is internally limited.

2.6 Special Adjustments

Max. ramp current

CP. 14

The following parameters serve to optimize the drive and adaption onto certain applications. These adjustments can be ignored at the initial startup.

This function protects the frequency inverter against switching off by overcurrent during the acceleration ramp. When the ramp reaches the adjusted value here, then it is stopped so long until the current decreases again. CP.2 displays "LAS" at active function.

Adjustment range:	10...200 %, 200% = oFF	up to case D
	10...200%; >150% = oFF	from case E
Resolution:	1 %	
Factory setting:	140 %	
Customer adjustment:	_____ %	


GB

Max. constant current

CP. 15

This function protects the frequency inverter against switching off due to overcurrent during constant output frequency. When exceeding the adjusted value here, the output frequency is reduced until the value drops below the adjusted value. CP. 2 displays "SSL" at active function.

Adjustment range:	10...200 %, 200% = oFF	up to case D
	10...200%; >150% = oFF	from case E
Resolution:	1 %	
Factory Setting:	200 %	
Customer adjustment:	_____ %	



Operation of the Unit

Speed search

CP. 16

When connecting the frequency inverter onto a decelerating motor, an error can be triggered by the differing rotating field frequencies. At activated on speed search the inverter searches the actual motor speed, adapts its output frequency and accelerates with the adjusted ramp onto the given set value. During speed search CP.2 displays "SSF". The parameter determines, under what conditions the functions operate. With several conditions the sum of the value must be entered. Example: CP.16 = 12 means after reset and after auto-reset UP

Adjustment range: 0...15
Resolution: 1
Factory setting: 8
Customer adjustment: _____


Value	Condition
0	function off
1	at control release
2	at switch on
4	after reset
8	after Auto-Reset UP

Voltage stabilization

CP. 17

This parameter can adjust a regulated output voltage in relation to the rated frequency. Because of this voltage variations at the input as well as in the intermediate circuit only have a small influence on the output voltage (U/f-characteristic). The function allows, among other things, an adaption of the output voltage onto the special motors. In the example below the output voltage is stabilized onto 230 V (0% boost).

Adjustment range: 150...649 V, OFF
Resolution: 1 V
Factory setting: OFF
Customer adjustment: _____ V



Slip compensation**CP. 18**

Slip compensation balances the speed changes caused by the load variation. In order to activate the function, set the value at 1.00 and optimize as directed in the examples below.

Adjustment range: -2.50...2.50
 Resolution: 0.01
 Factory setting: 0.00 (=off)
 Customer adjustment: _____


Autoboost**CP. 19**

Autoboost causes an automatic I^2R -compensation by raising the output voltage during high load torques. The magnetizing current remains constant. To activate the function set the value to 1.00 and optimize as directed in the examples below. Check the motor voltage to see, whether it returned to the normal value after no load of the drive. Otherwise reduce CP.19.


Adjustment range: -2.50...2.50
 Resolution: 0.01
 Factory setting: 0.00 (=off)
 Customer adjustment: _____



Slip compensation and autoboost work on the basis of presetting motor data. When using a special motor or in case of overdimensioning of more than one size, then both functions should be deactivated.



- 1) good - speed remains stable at increasing torque
- 2) bad - speed decreases with increasing torque
- 3) bad - speed is increased too much at load



DC-braking

CP.20

With DC-braking the motor is not decelerated by the ramp. Quick braking is caused by D.C. voltage, which is applied onto the motor winding. This parameter determines how the dc-braking is triggered.

Value	Activation
0	DC-braking deactivated
1	DC-braking at switch off of the direction of rotation and in reaching 0Hz. Braking time is dependent on CP.21 or until the next direction of rotation presetting.
2	DC-braking as soon as the direction of rotation presetting is absent. Braking time dependent on the real frequency
3	DC-braking, as soon as the direction of rotation changes. Braking time dependent on the real frequency.
4	DC-braking at switch off of the direction of rotation and the real frequency goes below 4 Hz.
5	DC-braking, when the real frequency goes below 4 Hz.
6	DC-braking, as soon as the set value goes below 4 Hz.
7	DC-braking, when input I3 (terminal X1.6/Version C) is switched. Braking time is dependent on the real frequency. At version S = value "0".
8	DC-braking as long as input I3 (terminal X1.6/Version C) is switched. At version S same as value "0".
9	DC-braking after switching on the modulation on. Braking time is dependent on CP.21.

Factory setting: 7

Note: Enter-Parameter

Customer adjustment: _____

Braking time

CP.21

The braking time is evaluated depending on CP.20 as follow:


- entered time = braking time
- entered time relates to 100 Hz and decreases/increases proportionally to the real frequency.

Adjustment range: 0.00...100 s

Resolution: 0.01 s

Factory setting: 10 s

Customer adjustment: _____



Calculation of the braking time:

$$t_{Breal} = \frac{CP.21 * f_{real}}{100 \text{ Hz}}$$

Relay output**CP.22**

Relay output (terminal X1.1...X1.3) is adjusted in the factory as a fault relay. This parameter can adjust the function of the output onto any function listed in the table below.

Value	Function
0	No function
1	Generally on
2	Fault relay
3	Fault relay (not at under voltage error)
4	Overload alert signal (10s before switch off)
5	Overtemperature alert signal inverter
6	Overtemperature alert signal motor (10s before switch off)
7	Only for application-mode
8	Max. constant current (stall, CP.15) exceeded
9	Max. LA-/LD-Stop (CP.14) exceeded
10	DC-braking active
11	Only for application mode
12	Rate of utilization (CP.3) > 100%
13	Only for application mode
14	Actual value = set value (CP.2 = Fcon, rcon; not at noP, LS, error, SSF)
15	Accelerate (CP.2 = FAcc, rAcc, LAS)
16	Decelerate (CP.2 = FdEc, rdEc, LdS)
17	Right handed rotation (not at noP, LS error)
18	Left handed rotation (not at noP, LS error)
19	Real direction of rotation = set direction of rotation
20	Real value > frequency level CP.23 (only version S)
21	Set value > frequency level CP.23 (only version S)
22	Only for application-mode
23	Operating signal (after initialization as long as no error is active)
24	Run signal
25...xx	Only for application-mode

Factory setting: 2

Note: Enter-Parameter

Customer adjustment: _____

Frequency value**CP.23**

This parameter determines the switching point for the relay output

- X1.21...X1.23 (only version C)

- X1.1...X1.3 (only version S at CP.22 = "20" or "21").

After the switching of the relay, the frequency can move within a 0.5 Hz window, without the relay dropping off.

Adjustment range: 0.0...409.58 Hz

Resolution: 0.0125 Hz

Factory setting: 4 Hz

Customer adjustment: _____

Operation of the Unit

Reference signal


CP.24

(only version C)

The set value input REF (terminal X1.17 / version C) can be driven by various signal levels. It operates cumulatively to the difference voltage input (terminal X1.8 and X1.9 / version C), but can also serve as the sole input to the set value presetting. In order to correctly evaluate the signal, this parameter must be adapted to the signal source.

Value	Set value signal
0	0...10V DC / $R_i = 4 \text{ kOhm}$
1	0...20mA DC / $R_i = 250 \text{ Ohm}$
2	4...20mA DC / $R_i = 250 \text{ Ohm}$

Factory setting: 0
Customer adjustment: _____



2.7 The Drive Mode

The drive mode is a operating mode of KEB COMBIVERT to start the drive manually by the operator. After switching the control release the set value and rotation presetting is done exclusively by the keyboard. In order to activate the drive mode the corresponding **password in CP.0** must be entered. The display switches over as follows.

Direction of rotation	Status
F=forward / r=reverse	noP = no control release / LS = neutral position

2.7.1 Start / Stop Drive

Modulation blocked
Drive not controlled



Drive decreases to 0 Hz and
switches the modulation off

Drive accelerates onto
the adjusted set value



Drive operates with
adjusted set value

2.7.2 Change Direction of Rotation

Drive changes direction
of rotation



2.7.3 Preset Set Value

Display changes when key is
pressed to set value display/
presetting



Set value can be changed
with UP/DOWN at pressed
FUNC/SPEED key

2.7.4 Leave Drive Mode

To exit the drive mode the inverter must be in status "stop" (Display noP or LS). Press the FUNC and ENTER keys simultaneously for about 3 seconds in order to leave the drive mode. The CP-parameters appear in the display.



+

ENTER
F/R

for 3 seconds

Error Diagnosis

3. Error Diagnosis

Undervoltage

E. UP

Error messages are represented with an "E. " and the corresponding error in the display of the KEB COMBIVERT. The displays and their causes are described below.

Occurs, when the intermediate circuit voltage falls below the permissible value.

Possible causes are

- input voltage too low or unstable
- inverter power too small
- voltage loss due to incorrect cabling
- power supply by generator/transformer breaks down, because ramps are too short

Overvoltage

E. OP

Occurs, when the intermediate circuit voltage rises above over the permissible value.

Possible causes are

- input voltage too high
- disturbance voltages at the input
- delay ramps too short

Overcurrent

E. OC

Occurs, when exceeding the peak current or when ground fault.

Overload

E. OL

Occurs when a too high load is applied for more than the allowed time (see "Performance Data"). Possible causes for this are

- error or overload in the application
- inverter incorrectly dimensioned
- motor incorrectly wired

After error E. OL you must wait for a cooling down time. This message appears after the cooling down phase is completed. The error can be reset.

Occurs, when the inverter temperature >70°C. Possible causes for this are

- insufficient cooling
- surrounding temperature too high
- ventilator clogged

Occurs, when external temperature monitoring is triggered. Possible causes for this are

- resistor on terminals OH/OH > 1650 Ohm
- motor overloaded
- break in the sensor cable

Internal or external excess-temperature error do not occur anymore. Error "E. OH" or "E.dOH" can be reset.

Current limit resistor error occurs for a short time during the turn on phase and is reset immediately. If the error message remains the following may be the cause


- incorrect or input voltage too small
- high loss in the supply line
- brake resistor incorrectly connected
- braking module defective

Display	Parameter	Adjust. range	Resolution	Customer setting
CP. 0	Password input	0...9999	1	-
CP. 1	Actual frequency display	-	0,1 Hz	-
CP. 2	Inverter status display	-	-	-
CP. 3	Actual load	-	1 %	-
CP. 4	Peak load	-	1 %	-
CP. 5	Rated frequency	0...409.58 Hz	0.0125 Hz	
CP. 6	Boost	0...25.5 %	0.1 %	
CP. 7	Acceleration time	0.01...300 s	0.01 s	
CP. 8	Deceleration time	0.01...300 s	0.01 s	
CP. 9	Minimal frequency	0...409.58 Hz	0.0125 Hz	
CP.10	Maximal frequency	0...409.58 Hz	0.0125 Hz	
CP.11	Fixed frequency 1	0...±409.58 Hz	0.0125 Hz	
CP.12	Fixed frequency 2	0...±409.58 Hz	0.0125 Hz	
CP.13	Fixed frequency 3	0...±409.58 Hz	0.0125 Hz	
CP.14	Max. ramp current	10...200 %	1 %	
CP.15	Max. constant current	10...200 %	1 %	
CP.16	Speed search	0...15	1	
CP.17	Voltage stabilization	150...649 V, off	1 V	
CP.18	Slip compensation	-2.50...2.50	0.01	
CP.19	Autoboost	-2.50...2.50	0.01	
CP.20	DC-braking	0...9	1	
CP.21	Braking time	0...100 s	0.01 s	
CP.22	Relay output	0...xx	1	
CP.23	Frequency value	0...409.58 Hz	0.0125 Hz	
CP.24	Reference signal (only C)	0...2	1	


The **function key** (FUNC) changes between the parameter value and parameter number.



With **UP** and **DOWN** the value of the parameter number is increased/decreased with **changeable** parameters.




Password input:




6. Password


a) CP-Parameter "read only"



b) CP-Parameter "read/write"



c) Drive mode activ



a)
100

b)
200

c)
500

D

Vor Auslieferung durchlaufen alle Produkte mehrfach eine Qualitäts- und Funktionskontrolle, so daß Fehler auszuschließen sind. Bei Beachtung unserer Betriebsanleitung sind keine Störungen zu erwarten. Sollte sich trotzdem ein Grund zur Reklamation ergeben, so ist das Gerät mit Angabe der Rechnungsnummer, des Lieferdatums, der Fehlerursache und den Einsatzbedingungen an uns zurückzusenden. Für Fehler, die aufgrund falscher Behandlung, falscher Lagerung oder sonstigen allgemeinen Irrtümern auftreten, übernehmen wir keine Verantwortung. Prospekte, Kataloge und Angebote enthalten nur Richtwerte. Technische Änderungen jeder Art behalten wir uns vor. Alle Rechte vorbehalten. Nachdruck, Vervielfältigung und fotomechanische Wiedergabe sind ohne schriftliche Genehmigung durch KEB auch auszugsweise verboten.

F

Avant la livraison tous les produits passent par différents contrôles fonctionnels et qualitatifs de manière à éliminer les mauvais fonctionnements. L'apparition de défauts sur ces produits est très improbable s'ils sont raccordés et utilisés selon les recommandations des manuels d'instructions. Néanmoins, si un défaut apparaissait, le matériel doit être retourné en indiquant le numéro du bon de livraison, la date d'expédition et les détails apparents du défaut ainsi que le type d'application. Un mauvais emploi, de mauvaises conditions de stockage ou d'autres causes de ce type excluent notre responsabilité en cas de défectuosité. Les documents techniques et commerciaux, les offres de prix ne contiennent que des valeurs standards. Nous nous réservons le droit de procéder à des modifications techniques sans préavis. Tout droit réservé. Toutes contrefaçons imprimées, ou reproductions photomécaniques; même partielles, sont strictement interdites.

GB

Prior to delivery all products pass several quality and performance inspections so that malfunctions can be ruled out. When used in accordance with the operating instructions failure is most unlikely. However, if you have cause for complaint the unit should be returned stating invoice number, delivery date, cause of failure and field conditions. We do not accept the responsibility for failures due to misuse, wrong storage or similar causes. Leaflets, catalogues and quotations contain only standard values. We reserve the right to make technical changes without obligation. All rights reserved. Any piratic printing, mimeographing or photomechanical reproduction, even in extracts, is strictly prohibited.

I

Prima di essere spediti, tutti i nostri prodotti sono soggetti a severi controlli di qualità e funzionamento, questo al fine di evitare malfunzionamenti. Se utilizzati seguendo il manuale di istruzione si evita qualsiasi malfunzionamento. Comunque, qualora dovesse verificarsi un guasto, l'unità dovrà essere rispedita specificando il numero di bolla, la data di spedizione, i dettagli del guasto ed il tipo di applicazione. Non si assumono responsabilità per errori dovuti a manomissioni, cattivo stoccaggio o simili. Ci riserviamo di effettuare qualsiasi modifica senza preavviso alcuno. Tutti i diritti sono riservati. Qualsiasi riproduzione non autorizzata, anche parziale, è rigorosamente proibita.

E

Antes de ser enviados todos los productos pasan severos controles de calidad por lo que pueden descartarse defectos. Cuando sea utilizado de acuerdo con las instrucciones de operación una avería no es nada probable. Sin embargo, si tiene motivo de reclamación la unidad podría devolverse indicando número de factura, fecha de entrega, causa del fallo y condiciones de instalación. Nosotros no aceptamos la responsabilidad por fallos debidos a mal uso, almacenaje incorrecto o causa similar. Los folletos, catalogues y ofertas contienen sólo valores estándar. Nos reservamos el derecho de modificar el equipo sin ninguna obligación. Todos los derechos reservados. Cualquier impresión pirata, reproducción mimeógrafia o fotomecánica, incluso en parte, está estrictamente prohibida.

RU

Перед отгрузкой все изделия неоднократно проходят проверку на предмет качества и работоспособность, так что брак исключается. При соблюдении нашего руководства по эксплуатации появление неисправностей не ожидается. Если вопреки этому, всё таки появятся основания для рекламации, изделие необходимо отправить на наш адрес с указанием номеров товарной накладной и счёта, датой поставки, причиной приведшей к выходу изделия из строя и условий эксплуатации.

Фирма КЕВ не несёт ответственность за выход изделий из строя по причинам не правильного хранения, транспортировки, неправильного обращения и других ошибочных действий. Проспекты, каталоги и коммерческие предложения содержат только ориентировочные значения. Мы оставляем за собой право вносить технические изменения любого рода. Все права принадлежат нам. Размножение, перепечатывание, фотомеханическое воспроизведение, даже частичное, без письменного разрешения на то фирмы КЕВ запрещено.



Karl E. Brinkmann GmbH

Försterweg 36-38 • D-32683 Barntrup
fon: +49 5263 401-0 • fax: +49 5263 401-116
net: www.keb.de • mail: info@keb.de

KEB Antriebstechnik GmbH & Co. KG
Wildbacher Str. 5 • D-08289 Schneeberg
fon: +49 3772 67-0 • fax: +49 3772 67-281
mail: info@keb-combidrive.de

KEB - YAMAKYU Ltd.
15-16, 2-Chome, Takanawa Minato-ku
J-Tokyo 108-0074
fon: +81 33 445-8515 • fax: +81 33 445-8215
mail: ky-sales@f4.dion.ne.jp

KEB Antriebstechnik Austria GmbH
Ritzstraße 8 • A-4614 Marchtrenk
fon: +43 7243 53586-0 • fax: +43 7243 53586-21
Kostelni 32/1226 • CZ-370 04 Ceské Budejovice
fon: +420 38 7319223 • fax: +420 38 7330697
net: www.keb.at • mail: info@keb.at

KEB - YAMAKYU Ltd.
711, Fukudayama, Fukuda
J-Shinjo-Shi, Yamagata 996 - 0053
fon: +81 233 29-2800 • fax: +81 233 29-2802
mail: ky-sales@f4.dion.ne.jp

KEB Antriebstechnik
Herenveld 2 • B-9500 Geraadsbergen
fon: +32 5443 7860 • fax: +32 5443 7898
mail: vb.belgien@keb.de

KEB Nederland
Leidsevaart 126 • NL-2013 HD Haarlem
fon: +31 23 5320049 • fax: +31 23 5322260
mail: vb.nederland@keb.de

KEB CHINA Karl E. Brinkmann GmbH
Shanghai Representative Office
(Xinmao Building, Caohejing Development Zone)
No. 99 Tianzhou Road (No.9 building, Room 708)
CHN-200233 Shanghai, PR. China
fon: +86 21 54503230-3232 • fax: +86 21 54450115
net: www.keb.cn • mail: info@keb.cn

KEB Portugal
Avenida da Igreja – Pavilão A n.º 261 Mouquim
P-4770 - 360 MOUQUIM V.N.F.
fon: +351 252 371318 + 19 • fax: +351 252 371320
mail: keb.portugal@netc.pt

KEB CHINA Karl E. Brinkmann GmbH
Beijing Representative Office
No. 36 Xiaoyun Road • Chaoyang District
CHN-100027 Beijing, PR. China
fon: +86 10 84475815 + 819 • fax: +86 10 84475868
net: www.keb.cn • mail: hotline@keb.cn

KEB Taiwan Ltd.
No.8, Lane 89, Sec.3; Taichung Kang Rd.
R.O.C.-Taichung City / Taiwan
fon: +886 4 23506488 • fax: +886 4 23501403
mail: kebtaiwan@seed.net.tw

Société Française KEB
Z.I. de la Croix St. Nicolas • 14, rue Gustave Eiffel
F-94510 LA QUEUE EN BRIE
fon: +33 1 49620101 • fax: +33 1 45767495
net: www.keb.fr • mail: info@keb.fr

KEB Sverige
Box 265 (Bergavägen 19)
S-4393 Hälsö
fon: +46 31 961520 • fax: +46 31 961124
mail: thomas.crona@keb.de

KEB (UK) Ltd.
6 Chieftain Business Park, Morris Close
Park Farm, Wellingborough **GB-Northants, NN8 6 XF**
fon: +44 1933 402220 • fax: +44 1933 400724
net: www.keb-uk.co.uk • mail: info@keb-uk.co.uk

KEBCO Inc.
1335 Mendota Heights Road
USA-Mendota Heights, MN 55120
fon: +1 651 4546162 • fax: +1 651 4546198
net: www.kebco.com • mail: info@kebco.com

KEB Italia S.r.l.
Via Newton, 2 • **I-20019 Settimo Milanese (Milano)**
fon: +39 02 33500782 • fax: +39 02 33500790
net: www.keb.it • mail: kebitalia@keb.it

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at artisantg.com for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

